

Tested substances	Concentration 100%	Temperature (°C)		
		20	60	100
(Di) ethyl ether	100	0		
(Di) ethyl formamide	100	+		
Acetic acid	100	+	+	
Acetic anhydride	100	+		
Acetone	100	+	0	
Almond oil	-	+	+	
Aluminum salts	t	+	+	+
Amides	t	+	+	
Ammonia (gas)	100	+	+	
Ammonium acetate	t	+	+	+
Ammonium carbonate	t	+	+	+
Ammonium chloride	t	+	+	+
Ammonium nitrate	t	+	+	+
Ammonium phosphate	t	+	+	+
Ammonium sulphate	t	+	+	+
Aniline	100	+	*	
Animal oil	-	+	-	
Antifreeze	-	+	+	
Apple juice	-	+	+	
Asphalt	-	+	0	
Aspirin	-	+		
Barium chloride	t	+	+	+
Battery acid	-	+	+	
Beer	-	+		
Benzaldehyde	100	+		
Benzaldehyde	Sat. solution(0,3)	+		
Benzine	100	+	0	
Benzoyl chloride	100	+	-	
Bleach	12,5% hloro	0	0	
Borax	Sat. solution	+	+	
Boric acid	100	+	+	
Boric water	Sat. solution(4,9)	+	+	
Bromine evaporation	High conc.	-	-	
Bromine evaporation	Low conc.	0	-	
Bromine solution	100	-		
Butane (gas)	100	+	+	
Butanol	100	+		
Butter	100	+	+	
Butyl acetate	100	*		
Butyl alcohol	-	+	+	*

+ = highly resistant

***** = resistant

0 = relatively resistant

Ø = poorly resistant

- = nonresistant

Calcium chloride	Sat. solution	+	+	
Calcium nitrate	Sat. solution	+	+	
Camphor oil	-	+	+	
Carbon disulphide	-	0		
Carbon tetrachloride	100		-	
Caustic soda	100	+	+	
Chlorine (dry gas)	100	-	-	-
Chlorine (gas)	100	0	-	-
Chlorine water	Sat. solution	0	-	
Chloroform	10		-	
Chrome acid	-	+	0	
Chrome trioxide	Sat. solution	+	-	
Chromium salts	Sat. solution	+	+	
Clove oil	-	+		
Coca Cola	-	+		
Coconut oil	-	+	*	
Copper nitrate	30%	+	+	+
Copper salts	Sat. solution	+	+	+
Corn oil	-	+	0	
Cresol	100	+	0	
Cyclohexane	100	+		
Cyclohexanol	100	+	+	
Decahydronaphtalene	100		-	-
Dioxane	100	+	0	-
Distillated water	100	+	+	+
Drinking water	-	+	+	+
Dry salt	-	+	+	
Ethyl acetate	100	0	0	
Ethyl alcohol	100	+		
Ethyl benzene	100	0	-	
Ethyl chloride	100	+		
Ethyl hexul alcohol	100	+		
Extracted cocoa	-	+	+	+
Extracted coffee	-	+	+	+
Flax oil	-	+	+	
Flour	-	+		
Formaldehyde	40	+	+	
Formic acid	-	+		
Fruit juice	-	+	+	
Fuel oil-masut	-	+	0	
Gasoline fumes	100	+	0	
Gelatine	-	+	+	*
Gin	40	+		
Glucose	-	+	+	+
Glycerin	100	+	+	
Glycolic acid	100	+	+	

+ = highly resistant

***** = resistant

0 = relatively resistant

Ø = poorly resistant

- = nonresistant

Heptane	100	*	0	
Hexane	100	+	0	
Hydrochloric acid	High conc.	+	+	
Hydrochloric acid	Low conc.	+	+	
Hydrochloric acid	10	+	+	
Incense	100	-		
Incense oil	-	0	-	
Iodine solution	-	+		
Iron salts	Sat. solution	+	+	+
Isooctane	100	+	0	
Isopropyl alcohol	100	+	+	
Lactic acid	-	+	+	
Lake water	-	+	+	+
Lanolin	-	+	0	
Lemonade	-	+		
Liqueurs	t	+		
Liquid ammonium	conc..	+	+	
Liquid butane	100	+		
Liquid chlorine	100	-		
Liquid dioxane	-	+	+	+
Liquid glycerin	Low conc.	+	+	+
Liquid propane	100	+		
Liquid soap	10	+	+	+
M(I),M(III) bisulphate dodecahydrate	Sat. solution	+	+	
Magnesium salts	Sat. solution	+	+	+
Margarine	-	+	+	
Marmalade	-	+	+	*
Mayonnaise	-	+		
Menthol	-	+		
Mercury	100	+	+	
Methanol	100	+	+	
Methyl chloride	100	0		
Methyl ethyl ketone	100	+	0	
Milk	-	+	+	*
Mint oil	-	+	+	
Motor oil	-	+	0	-
Mustard	-	+	+	
Naphtha (diesel)	-	+	0	
Naphtha/oil	100	+		
Naphthalene	100	+		
Naphthalene tetrachloride	100	0	-	
Nickel salts	Sat. solution	+	+	
Nitric acid	10	*	-	-
Nitrobenzene	100	*	0	

+ = highly resistant

***** = resistant

0 = relatively resistant

Ø = poorly resistant

- = nonresistant

Octane	-	+	0	
Oil of European hake	-	+		
Oleic acid	100	+		
Oleum	t	-	-	-
Olive oil	-	+	+	
Orange/lemon juice	-	+	+	
Oxalic oil	-	+	+	+
Ozone	<0,5ppm.	*		
Paraffin	100	+	+	-
Paraffin oil	-	+	0	-
Peanuts oil	-	+	*	
Pepper	-	+	+	
Perfume	-	+		
Phenol	Sat. solution	+	+	
Phosphoric acid	Sat. solution	+	0	
Phosphorus oxychloride	100	0	-	-
Photographic acid	-	+	+	
Pine resin oil	-	+	*	
Potassium carbonate	Sat. solution	+	+	
Potassium chlorate	Sat. solution(7,3)	+	+	
Potassium chloride	Sat. solution	+	+	+
Potassium chromate	Sat. solution(12)	+	+	+
Potassium iodide	Sat. solution	+	+	
Potassium nitrate	Sat. solution	+	+	
Potassium permanganate	Sat. solution(6,4)	+	*	
Potassium persulfate	Sat. solution(0,5)	+		
Potassium sulfate	Sat. solution	+	+	+
Propane (gas)	100	+	+	
Pyridine	100	+	0	
Quinine	-	+		
Salt water	-	+	+	+
Silicon oil	-	+	*	
Silver salt	Sat. solution	+	+	
Soda	-	+		
Sodium bicarbonate	Sat. solution	+	+	+
Sodium carbonate	Sat. solution	+	+	
Sodium chlorate	25	+	+	
Sodium chloride	5	+		
Sodium chloride	Sat. solution	+	+	+
Sodium hypochlorite	5	+	+	
Sodium nitrate	Sat. solution	+	+	

+ = highly resistant

***** = resistant


0 = relatively resistant

Ø = poorly resistant

- = nonresistant

Sodium perborate	Sat. solution(1,4)	+	+	+
Sodium phosphate	Sat. solution	+	+	+
Sodium sulphate	Sat. solution	+	+	+
Sodium sulphite	Sat. solution	+	+	
Sodium thiosulphate	Sat. solution	+	+	
Stone layer/tartar	-	+	+	+
Succinic acid	Sat. solution	+	+	
Sulphonic chloric acid	100	-	-	-
Sweet cream	-	+		
Tea	-	+	+	*
Tetrachlorethylene	100	0	-	
Tetrahydrofuran	100	0	-	
Thiophene	100	0	-	
Tin chloride	Sat. solution	+	+	
Tooth paste	-	+	+	
Trichloroethylene	100	0		
Trihydric phosphate	-	+		
Urea	Sat. solution	+	+	
Vanilla	-	+	+	
Vaseline	-	+	0	
Water saturated with oxygen	3	+	+	+
Water saturated with oxygen	10	+	+	
Wax	-	+	0	
Xylene	100	0	-	

Liquids that can not be transported through FLUIDTERM pipes

	<p>Aqua regia / acid regia, aliphatic hydrocarbon , benzene, bromine water, liquid bromine, butyl acetate, camphor oil, chlorine , chloroform, chloresulphonic acid , cyclohexanone, decaling , ethyl acetate, ethyl chloride, heptanes, isooctane, nitric acid, methyl bromide, oleic acid, oleum, paraffin oil, sulphuric acid, tetrahydrofuran, tetrahydronaphtalene , toluene (Toulon C₆H₅CH₃), trichloroethylene, turpentine, xylene.</p>
---	---

+ = highly resistant

***** = resistant

0 = relatively resistant

Ø = poorly resistant

- = nonresistant